

MOTOPLASTIC, S.A.

Molí de la sal, 1 - 08403 Granollers (Barcelona) SPAIN

Tel. 34 93 849 06 33 - Fax 34 93 849 09 88

info@puig.tv - info@puigusa.com

www.puig.tv - www.puigusa.com

| ID. | DESCRIPCIÓN                     | DESCRIPTION                        | REF.            | QTY. |
|-----|---------------------------------|------------------------------------|-----------------|------|
| 1   | Pantalla                        | Windshield                         | I0149H/W        | 1    |
| 2   | Tuerca M5 DIN982                | M5 DIN982 nut                      | TUERCA-D982-746 | 4    |
| 3   | Tornillo phillips M5x13         | M5x13 phillips screw               | TORNIPS10---233 | 4    |
| 4   | Tornillo M5x20 DIN912           | M5x20 DIN912 screw                 | TORNI-AD912-464 | 4    |
| 5   | Semibrida rótula tuerca         | Semi-clamp ball-joint nut          | BRIROT01-I-PR16 | 2    |
| 5   | Semibrida rótula tornillo       | Semi-clamp ball-joint screw        | BRIROT02-I-PR16 | 2    |
| 6   | Semi-casquillo manillar Ø22mm   | Medium-spacer Ø22mm                | CAS29-22-0-PR16 | 4    |
| 7   | Semi-casquillo manillar Ø26mm   | Medium-spacer Ø26mm                | CAS29-26-0-PR16 | 4    |
| 8   | Tornillo M8x50 DIN912           | M8x50 DIN912 screw                 | TORNI-D912--631 | 2    |
| 9   | Tuerca M8DIN982                 | M8 DIN982 nut                      | TUEA-D985.8-M8- | 2    |
| 10  | Guía varilla                    | Rod guide                          | FIXVARLL-0-PR16 | 2    |
| 11  | Brida anterior manillar         | Front clamp handlebar              | BRIDAANT-0-PR16 | 2    |
| 11  | Brida posterior manillar        | Rear clamp handlebar               | BRIDAPOS-0-PR16 | 2    |
| 12  | Varilla Dim. 4x20mm Inox        | Rod Dim. 4x20mm Inox               | VARILI4X20--576 | 2    |
| 13  | Conjunto rótula                 | Ball bearing set                   | CJROTULA-0-P200 | 2    |
| 13  | Varilla con rótula Dim. 9x200mm | Rod with ball bearing Dim. 9x200mm | VARILF9X200-591 | 2    |
| 14  | Conjunto soporte                | Support set                        | CONJU-S3PCC-003 | 2    |
| 15  | Tope exterior goma              | Rubber outer stop                  | TOPEE-VPGT--8/4 | 2    |
| 16  | Embellecedor Faro               | Headlight Trim                     | RIBETEHP--900H  | 1    |
| 17  | Tapón tornillo M6 DIN912        | M6 DIN912 screw cap                | TAPA--CHCI1450E | 2    |

## INSTRUCCIONES DE MONTAJE - MOUNTING INSTRUCTIONS - MONTAGEANLEITUNG

### CARENABRÍS MODELO - WINDSHIELD MODEL - WINDSCHUTZSCHEIBE MODEL CUSTOM II

Ref.: 0336

