


SHAD

CF MOTO MT 800 '21-

TOP MASTER C0MT81ST

BCN




1 263085 x 1



2 260900 x 2
Ø16 Ø9 x 36



3 303045 x 2
Ø8



4 304228 x 2
M8 x 100 DIN 7380



5 260523 x 2
Ø16 Ø9 x 25



6 303025 x 2
Ø10



7 304032 x 2
M8x50 DIN 7991

WARNING!

(GB) Do not fully tighten the screws until it is ensured that the KIT is correctly attached and aligned.

(E) No apretar los tornillos del todo hasta asegurarse que el KIT está correctamente colocado y alineado.

(D) Ziehen Sie die Schrauben nicht ganz fest, bevor Sie sich nicht vergewissert haben, daß der Bausatz korrekt eingestellt und ausgerichtet ist.

(I) Non stringere del tutto le viti fin tanto non si è sicuri che il kit è collocato correttamente e allineato.

(F) Ne pas serrer les vis avant d'être sûr que le KIT soit correctement positionné et ajusté.

