


SHAD

ARIIC CHINF 318 '21 TOP MASTER A0CH31ST



1 262735 x1 →
262736 x1 ←




2 261277 x2
Ø20 Ø11 x 25



3 261072 x2
Ø20 Ø9 x 32



4 303045 x4
Ø8



5 304170 x4
M8 x 60 Din 7380

! WARNING!

(GB)

Do not fully tighten the screws until it is ensured that the KIT is correctly attached and aligned.

(E)

No apretar los tornillos del todo hasta asegurarse que el KIT está correctamente colocado y alineado.

(D)

Ziehen Sie die Schrauben nicht ganz fest, bevor Sie sich nicht vergewissert haben, daß der Bausatz korrekt eingestellt und ausgerichtet ist.

(I)

Non stringere del tutto le viti fin tanto non si è sicuri che il kit è collocato correttamente e allineato.

(F)

Ne pas serrer les vis avant d'être sûr que le KIT soit correctement positionné et ajusté.

