


SHAD

ZONTES T310 '19

KIT TOP Z0T319ST



1 262466 x1



2 260417 x4
Ø16 Ø9 x 16



3 303045 x2
Ø8



4 304039 x2
M8 x 40 Din 7380



5 303025 x2
Ø10



6 304088 x2
M8 x 35 Din 7991



WARNING!

GB Do not fully tighten the screws until it is ensured that the KIT is correctly attached and aligned.

E No apretar los tornillos del todo hasta asegurarse que el KIT está correctamente colocado y alineado.

D Ziehen Sie die Schrauben nicht ganz fest, bevor Sie sich nicht vergewissert haben, daß der Bausatz korrekt eingestellt und ausgerichtet ist.

I Non stringere del tutto le viti fin tanto non si è sicuri che il kit è collocato correttamente e allineato.

F Ne pas serrer les vis avant d'être sûr que le KIT est correctement monté et ajusté.

