


SHAD

VOGE 500 DS '20 TOP MASTER VODS50ST



1 262693 x1



2 260417 x1
Ø16 Ø9 x 16



3 303045 x3
Ø8



4 304169 x1
M8 x 50
Din 7380



5 304032 x2
M8 x 50
Din 7991



6 260740 x2
Ø20 Ø11 x 11



7 262694 x2



8 302024 x2
M8

! WARNING!

(GB)

Do not fully tighten the screws until it is ensured that the KIT is correctly attached and aligned.

(E)

No apretar los tornillos del todo hasta asegurarse que el KIT está correctamente colocado y alineado.

(D)

Ziehen Sie die Schrauben nicht ganz fest, bevor Sie sich nicht vergewissert haben, daß der Bausatz korrekt eingestellt und ausgerichtet ist.

(I)

Non stringere del tutto le viti fin tanto non si è sicuri che il kit è collocato correttamente e allineato.

(F)

Ne pas serrer les vis avant d'être sûr que le KIT soit correctement positionné et ajusté.

