


SHAD

SYM SYMPHONY 125 '15

KIT TOP SOSM15ST



1 261845 x1



2 260821 x4
Ø14 Ø9 x 22



3 303017 x2
Ø6



4 304176 x2
M6 x 50 DIN 912



5 304093 x2
M6 x 40 DIN 7991



6 302021 x4
M6



WARNING!

GB Do not fully tighten the screws until it is ensured that the KIT is correctly attached and aligned.

E No apretar los tornillos del todo hasta asegurarse que el KIT está correctamente colocado y alineado.

D Ziehen Sie die Schrauben nicht ganz fest, bevor Sie sich nicht vergewissert haben, daß der Bausatz korrekt eingestellt und ausgerichtet ist.

I Non stringere del tutto le viti fin tanto non si è sicuri che il kit è collocato correttamente e allineato.

F Ne pas serrer les vis avant d'être sûr que le KIT est correctement monté et ajusté.

