

SHAD

HONDA CB 500F / CBR 500R '14

HOCF54iF



- | | | | | | |
|-------------------------------------|--|-------------------------------------|---------------------------|--|---|
| | | | | | |
| 1 261735 x1 →
261736 x1 ← | 2 261743 x1 →
261744 x1 ← | 3 261737 x1 →
261738 x1 ← | 4 202478 x2 | 5 201672 x4
Ø18 Ø12 Ø7 x 7,5-2 | 6 304057 x4
M6 x 25 DIN 912 |
| | | | | | |
| 7 303000 x4
Ø6 | 8 304081 x4
M8 x 20 DIN 7380 | 9 303020 x16
Ø8 | 10 302024 x6
M8 | 11 304170 x1
M8 x 60 Din 7380 | 12 304053 x5
M8 x 30 DIN 7380 |

WARNING!

(GB)

Do not fully tighten the screws until it is ensured that the KIT is correctly attached and aligned.

(E)

No apretar los tornillos del todo hasta asegurarse que el KIT está correctamente colocado y alineado.

(D)

Ziehen Sie die Schrauben nicht ganz fest, bevor Sie sich nicht vergewissert haben, daß der Bausatz korrekt eingestellt und ausgerichtet ist.

(I)

Non stringere del tutto le viti fin tanto non si è sicuri che il kit è collocato correttamente e allineato.

(F)

Ne pas serrer les vis avant d'être sûr que le KIT est correctement monté et ajusté.



