

SHAD

KAWASAKI Z800 ('13 - '17)

SIDE BAG HOLDER K0Z883SE



- | | | | | |
|-------------------------------------|--|--|---------------------------|---------------------------|
| 1 261879 x1 →
261880 x1 ← | 2 260213 x1
Ø16 Ø9 x 12 | 3 304066 x1
M5 x 40 Din 7380-2 | 4 302027 x1
M5 | 5 303025 x1
Ø10 |
| 6 302032 x1
M10 | 7 304283 x1
M10 x 70 Din 912 | 8 304179 x2
M6 x 65 Din 912 | 9 303017 x13
Ø6 | 10 302021 x4
M6 |

WARNING!

(GB)

Do not fully tighten the screws until it is ensured that the KIT is correctly attached and aligned.

(E)

No apretar los tornillos del todo hasta asegurarse que el KIT est correctamente colocado y alineado.

(D)

Ziehen Sie die Schrauben nicht ganz fest, bevor Sie sich nicht vergewissert haben, daß der Bausatz korrekt eingestellt und ausgerichtet ist.

(I)

Non stringere del tutto le viti fin tanto non si sicuri che il kit collocato correttamente e allineato.

(F)

Ne pas serrer les vis avant d' être sûr que le KIT est correctement monté et ajusté.



