


# SHAD

## CF MOTO MT 800 '21- TOP MASTER COMT81ST

BCN




**1** 263085 x 1



**2** 260900 x 2  
Ø16 Ø9 x 36



**3** 303045 x 2  
Ø8



**4** 304228 x 2  
M8 x 100 DIN 7380



**5** 260523 x 2  
Ø16 Ø9 x 25



**6** 303025 x 2  
Ø10



**7** 304032 x 2  
M8x50 DIN 7991

### WARNING!

**GB** Do not fully tighten the screws until it is ensured that the KIT is correctly attached and aligned.

**E** No apretar los tornillos del todo hasta asegurarse que el KIT está correctamente colocado y alineado.

**D** Ziehen Sie die Schrauben nicht ganz fest, bevor Sie sich nicht vergewissert haben, daß der Bausatz korrekt eingestellt und ausgerichtet ist.

**I** Non stringere del tutto le viti fin tanto non si è sicuri che il kit è collocato correttamente e allineato.

**F** Ne pas serrer les vis avant d'être sûr que le KIT soit correctement positionné et ajusté.

